NALCO SERVICES REPORT



Client: <u>Albany</u> Memorial Hospital

Site Address: 600 Northern Blvd. Albany, NY 12204

Attention: Larry Tilton

Copies To: Dakota Snyder, Mike Pidlypchak

Purpose of visit: Routine Envirox Service

Water Analysis and Performance Indicators										
Envirox Location	Alarms?	ClO₂ Monitor Reading	CIO ₂ DPD Test	CIO ₂ Probe Re- calibrated?	CIO ₂ Probe Rebuilt?	WM GPM	Water Meter Total	Prefilters Changed?	Gallons of NaClO ₂ Online?	CIO2 Dosing Pump Settings
Cold	No	0.57	0.58	No	No	128	8571268	No	13.5	62%
				Operatio	nal System					

	Operational System Checks								
Envirox Location	Incoming Water Hardness	Softener	Pump	Pump	Generator internal PSI? (2-10)	Cassette Voltages (8-35)	Cassette Hours x/x/x/x	Salt in Brine Tank?	
Main	50 ppm	0 ppm	Yes	No	5.7	27.2 / 27.3	951 / 951	Yes	

Domestic Water System Representation								
Location	1st Floor Emergency	2nd Floor Hand Break Room	4th Floor CCD Rm#3	6th Floor Room# 623	6th Floor South Waiting			
Time	10:12 am	10:25 am	10:45 am	11 am	11:20 am			
CLO ₂ Test	Hot- ND Cold- 0.29	Hot- 0.02 Cold- 0.46	Hot- ND Cold- 0.35	Hot- ND Cold- 0.36	Hot- ND Cold- 0.48			
Odor? Y/N	No	No	Hot Chlorite- 0.76	Hot Chlorite- 0.74	No			

Inventories								
Envirox Location	# of Cassettes		Generator & Monitor Pre- filters	Dosina	up (Lbs)	CIO2 Probe Rebuild Kits	Electrolyte (ml)	Dosing Pump Rebuild Kits
Main	0 NSF 1000	13.5	MAC-18	6	30	1	N/A	1
			GenC-3					

Final Checks: Timer setting = 0 min/hr $\sqrt{}$ Electronic Valve = 55-65% $\sqrt{}$ Check for leaks $\sqrt{}$ Feedwater PSI = 35-40 $\sqrt{}$

Comments: All equipment is operating normally. Cold CIO2 residuals have improved since last visit. The drain for the generator seems to be backing up, I would advise an acidic drain cleaner.

Parts for next trip:

HYG-25, 55 gal.

Note: CIO2 = (Chlorine Dioxide), NaCIO2 = (Sodium Chlorite, HYG-25, Precursor)

Technician:	Colin	Mossbrucker

Date:_1/4/2019

Ŵ

Customer Signature:____

Nalco makes no warranties with respect to water system biohazards from waterborne pathogens including but not limited to Legionella bacteria. Nalco does not and cannot make any guarantee or warranty that the risk of the presence of Legionella or the risk of legionellosis has been reduced or eliminated by reason of the Program.

Signature: